



## SB.2I PARKING BARRIER

### **INSTALLATION, ASSEMBLY & USER INSTRUCTIONS**

(Read in full before starting)

#### **SAFETY**

We recommend the following minimum precautions are taken:

Wear appropriate safety clothing.

Eye protection and hand protection should be worn, including safety helmet.

Wear strong protective gloves.

Secure the site from pedestrians and vehicles, where applicable by the use of high visibility tape, barrier, cones, safety lamps etc.

If you use power supply ensure that it is secure and safe in a dry location.

Ensure there are no underground services that may be affected.

A minimum of two personnel are recommended.

#### **INSTALLATION INSTRUCTIONS**

Determine correct position of post.

Foundations 400mm cubed should be dug out to accommodate concrete plinth.

Depth of concrete plinth can be reduced dependant on what surface block is to be cast into. Pour concrete and ensure that finished plinth is smooth and level using a trowel or float. It is essential that concrete base is smooth and level once dry for the post to lock correctly.

Once concrete has cured position post on a smooth level plinth using the base as a template to drill four 12mm holes 100mm deep. The base plate can now be secured into position with four M14 x 75mm anchor bolts, once secured check for smooth operation of lock and post.

#### **MAINTENANCE**

Occasionally clean all surfaces with soap and water.

Check all fixing bolts and other visible fixings are suitably tight and have not worked loose.

Check foundations remain firm.

Redbrook Lane Ind Este  
Brereton  
Rugeley  
Staffordshire  
WS15 1QU

Tel: 01889 577 347  
Fax: 01889 586 913

Email: [sales@ccp-solutions.co.uk](mailto:sales@ccp-solutions.co.uk)  
Web: [www.ccp-solutions.co.uk](http://www.ccp-solutions.co.uk)

---

Company Reg No. 7141856

---

V.A.T. Reg No. 985 1348 88

---

Directors:  
D.K.Butler  
J.T.Parkes

---

